

# December 3, 2018

### Winter is Here

### **Professional Drivers Need to Know How to Adjust for Winter Conditions**

#### To meet winter driving expectations, you must:

- Recognize that snow and ice don't cause accidents people do;
- Adjust your driving techniques to meet winter driving demands; and,
- Recognize that YOU control your vehicle, the speed and the space.

## It all comes down to three key principles:

- Slow down
  Leave more space around your vehicle
  Keep a safe following distance (no less than 6 seconds; increasing when the weather is foul).

#### When you slow down and leave more space, you'll be prepared if:

- You need to stop unexpectedly because other vehicles are stopped, broken down, or pulled over to the side of the road.
- You experience poor traction due to snow, water, and/or ice on the road.
- Your tires spin because of a slippery, icy road surfaces.
- You encounter shiny spots of black ice on the road.
- You have reduced visibility due to snow and spray from the road.

#### **Winter Driving Reminders:**

- Gentle, early braking reduces the risk of skidding.
- Avoid sudden starts, stops, and turns.
- High volume traffic on snow covered roads, curves, and intersections makes them become slicker than usual because the snow and ice become packed down.
- Stay back from large vehicles that spray excessive water and snow.
- Use turn signals and brake lights early to warn other drivers of your expected movements.
- Check your wiper blades, washer fluid, and defroster before each trip.
- Make sure your headlights, turn signals, and brake lights are free from snow.
- Prevent skidding by gently steering in the direction you want to go.